



| | | | | | |
|--|---------------------------------|--|---|-----------------|------------------------------|
| A ED0052 17mm Hex Head/ torque wrench | B ED0056 | C ED0054 17mm Hex Head/ torque wrench | D ED0508 | E ED0308 | J ED0055 RHS CABLE |
| F 8442LT | G ED0059 10mm Spanner | K | NOTE TOP OF CABLES thin Part E inserted on either side of RHS cable Note: direction of Ferrell bend - slides 7 + 9 BOTTOM OF CABLES thin Part E inserted on either side of RHS cable Note: direction of Ferrell bend - slide 11 I 645335 L ED0051 H 001649 | | |

EZDown Reloaded Instruction - 1st Fitment

EZDown Reloaded Hilux/Revo 2016 - RL0050

1
RHS and LHS are determined when sitting in the Drivers side of the Vehicle.
NB: Remove rubber grommets as shown slides 2 - 4 and discard

NB: Locktite all fixing/mounting points where applicable.

After full fitment remove labels from the cable.

2

3

4

NB: Remove RHS rubber grommet from side panel as shown

Tooling: Phillips head screw driver No 3. If OEM Bolt is very tight apply heat to remove e.g Heat Gun

5

Tooling: Torx Bit T40

6

13mm Hex head spanner

7

Fit RHS as indicated on cable stickers, then remove stickers.

8

17mm Hex head spanner

Ensure Ferrell Bend follows shape of vehicle panel.

9

Fit damper.
10mm Hex head spanner

10

X Note direction of ferrell bend

11

Tail light

12

Ensure Bottom Ferrule bend is facing away from Tailgate.

13

If Cable does not align automatically and cable protrudes when bin is closed, place pressure onto Ferrule and press toward vehicle tailgate.

In case cable is too tight against the tailgate slightly pull away from the tailgate and straighten the cable.

14

15

NB: HAVE YOU REMOVED YOUR RUBBER GROMMETS - RHS ONLY (2 IN TOTAL) AS INDICATED IN SLIDES 2 - 4?

Online video installation

| FITTING CODE | MANUFACTURER | MODEL TYPE | YEAR | STOCKIST | PRODUCT | REVISION | LABOUR | DATE | PAGE |
|--------------|--------------|------------|--------------|--------------|-----------------|----------|--------|----------------------|------|
| RL0050 | TOYOTA | REVO | 2016 onwards | GENERAL USE | EZDOWN RELOADED | 8 | 25min | 12/01/2023 | 1 |
| TORQUE - N.m | ★ 27N.m±2N.m | | | ★ 15N.m±2N.m | | | | www.ezdownshop.co.za | |

NB: After installation please close tailgate gently to ensure that there is no interference with any hardware.

IMPORTANT:
No liability will be incurred by Industrial Specialised Applications company, for injury, death, or property damage caused by a product which has been set up, operated, and/or installed contrary to EZDown installation guide/manual, or which has been subjected to misuse, negligence, or accident, or which has been repaired or altered by anyone other than Industrial Specialised Applications, or which has been used in a manner or for a purpose for which the product was not designed.

